



GK-816 LIGHT-UP GAMING KEYBOARD

OWNER'S MANUAL —

Before installing and using the product, please read the instructions thoroughly and retain them for future reference.

8036986A



KEYBOARD FEATURES:

- 15 fully programmable keys with custom macro function
- Select from 3 variations of LED rainbow lighting LED each option has 7 LED colours
- · Plug & Play connectivity
- Supports Windows ME/2000/XP/Vista/7/8/8.1/10
- · 26-key anti-ghosting allows you press up to 26 keys simultaneously

KEYBOARD FUNCTIONS:

- 1. This keyboard supports 26 simultaneous key presses. ("Q", "A", "Z", "W", "S", "X", "E", "D", "C", "R", "F", "V", "T", "G", "B", "M", "Space", "↑(UP)", "↓(Down)", "←(Left)", "(Right)→", "Tab", "Ctrl-L", "Shift-L", "Alt-L", "Capslock")
- 2. Press the LED **■** key to turn the LED lighting on or off.
- To adjust the backlight lighting: Press FN+Page Up to increase brightness, Press FN+Page Down to decrease the brightness. The default backlight brightness is the middle brightness.
- 4. Turn on the pulsing light mode by pressing "FN+≣▶", Speed up the light pulsing rate by press FN+"=", slow down the pulsing rate by pressing FN+"-".
- Press FN+Q to adjust keystroke retransmission speed (2 gears, the default is the normal speed)
- 6. Support 3 custom macros <M1-M3>, (Rec G1-G5) and can be manually recorded. 15 bytes can be recorded for each macro.

CUSTOMIZED PROGRAMS QUICK GUIDE:

M1 (G1-G5)

- 1. Press M1
- Press record key , indicator lights of NUM/Caps LOCK/Win LOCK will flash slowly.
- 3. Press G1, indicator lights of NUM/Caps LOCK/Win LOCK will flash fast.
- Edict the program that you want to edit (15 bytes and 30 seconds typing time limit)
- Press record key again to finish the command, indicator lights of NUM/Caps LOCK/Win LOCK will stop flashing and come to normal state before programming.
- 6. Similar steps to define G2-G5 programs.

M2 (G1-G5)

- 1. Press M2
- Press record key , indicator lights of NUM/Caps LOCK/Win LOCK will flash slowly.
- 3. Press G1, indicator lights of NUM/Caps LOCK/Win LOCK will flash fast.
- Edict the program what you want to edit (15 bytes and 30 seconds typing time limit)
- Press record key again to finish the command, indicator lights of NUM/Caps LOCK/Win LOCK will stop flashing and come to normal state before programming.
- 6. Similar steps to define G2-G5 programs.

Use same way to customize programming M1 (G2-G5), M2 (G2-G5) and M3 (G1-G5).

Press and hold "Fn+ or 2 seconds to delete recording information, backlight flashes 3 seconds to exit automatically. If beyond the byte or time, recording will be automatically exited.

Fn+	F1 <u>•</u>	Media
Fn+	F2 <u>1</u>	Volume –
Fn+	F3 <u>••</u>	Volume +
Fn+	F4	Volume Mute
Fn+	F5 <u></u>	Volume Stop
Fn+	F6 <u>₩</u>	Previous Track
Fn+	F7 <u>≥II</u>	Play/Pause
Fn+	F8 <u>₩</u>	Next Track
Fn+	F9 🔤	Email
Fn+	F10 🧰	Home
Fn+	F11 <u>d</u>	Lock
Fn+	F12 🗏	Calculator
Fn+	Win-L ₫	Lock Win
Fn+	W	Exchange AWSD with arrows
Fn+	Q	Adjust typing rate (2 levels)

Fn+	≣▶	Turn on backlight and breathe
Fn+	()	Slow down backlight changing speed
Fn+	(+=)	Speed up back light changing speed
	■	Shift between 3 colours
Fn+	Page Up	Backlight lighter
Fn+	Page Down	Backlight darker
Fn+		Clear macro function
Fn+	*	Backlight control

THE FCC WANTS YOU TO KNOW

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for additional suggestions.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Where shielded interface cables have been provided with the product or specified additional components or accessories elsewhere defined to be used with the installation of the product, they must be used in order to ensure compliance with FCC regulation.

CAN ICES-3(B)

THE SOURCE - WARRANTY



The Source warrants that this product will be free from defects in materials and workmanship for a period of twelve (12) months from the date of purchase. Within this period, simply take the product and your proof of purchase to any The Source store or participating dealer and the product will be replaced (where available) without charge. Any product which has been subject to misuse or accidental damage is excluded from this warranty.

This warranty is only applicable to a product purchased through The Source company-owned stores or participating dealers in Canada where the warranty is included with the product. While this warranty does not confer any legal rights other than those set out above, you may have additional statutory rights which will vary under the laws of the various countries, states, provinces and other governmental entities in which The Source operates. This warranty is subject to all statutory rights you may have in Canada.

Imported by The Source Barrie, Ontario, Canada, L4M 4W5 Manufactured in China For product support please visit www.thesource.ca



© 2017 The Source All rights reserved.

Please Recycle