





Extreme Power


The Mobile X1 is the highest power 50db gain wireless mobile booster on the market. It will keep you connected where other boosters fail. It boosts signal to all cell phones and cellular devices within the booster's range simultaneously. This is a wireless booster that does not require a physical connection to the cell phone or cellular data device. The Smoothtalker Mobile X1 High Power Booster is the most technologically advanced wireless cellular signal booster made. It features proprietary "Stealthtech technology" that prevents shutdowns from poor antenna placement and changing environment. This booster has 50dB of gain and provides coverage throughout your car, truck RVs, Boats, work trailers.

HOW IT WORKS:

The Booster captures the signal outside the vehicle and boosts it to the phone. It takes the weak signal from the phone and boosts it back to the tower. Boosts both voice and data simultaneously.

WHERE CAN THIS BOOSTER BE USED:

The Mobile X1 50 is used primarily in vehicles but can also be used in a fixed location such as in a Motorhome or on a desktop.




HOW LARGE AN AREA WILL IT COVER:

Coverage area is effected by two things. Outside signal and booster gain. Generally the booster will cover the whole space in a car or pick up truck. In the case where it is used in a boat or RV the range will be limited by the outside signal level. See the Mobile X2 Pro for larger areas.

Mobile X1 -Outside signal level and coverage expected:

5 bars outside	distance from inside antenna	60 ft.
4 bars outside	distance from inside antenna	40 ft.
3 bars outside	distance from inside antenna	20 ft.
2 bars outside	distance from inside antenna	10 ft.
1 bar outside	distance from inside antenna	5 ft.
0 bars	may or may not work	

ASSESSING YOUR OUTSIDE CELLULAR SIGNAL LEVEL



HOW FAR AWAY FROM THE TOWER CAN I EXPECT TO GET WITH BOOSTER:

Mobile X1 50 is the most powerful mobile wireless booster on the market and can keep you connected up to 35mi. (60 km) from the nearest tower.

USE SIGNAL BAR INDICATOR Use the signal bar indicator on your cellular device to approximate signal strength as per the chart above.

Note: Even if your device shows no bars or "no service" it is possible that there is enough cellular signal for a booster to achieve communication with the network.

TIPS ON SET UP

- Mount outside antenna in the center of the vehicle roof except in cases where a sunroof is present. In this case mount the antenna towards the back of the vehicle in the center of the metal portion of the roof. Inside and outside antennas require distance (separation) to avoid feedback loop (oscillation) and gain reduction. Mount the inside
- antenna in the console or close to the floor away from the windows and windshield. · Flashing green LED lights indicate gain reduction. If the green lights on the booster are flashing, please refer to the
- user manual for instructions.

STEALTHTECH TECHNOLOGY(proprietary Smoothtalker technology): Mobile X1 amplifiers and boosters use STEALTHTECH® to automatically control gain to eliminate feedback loops (oscillations)

and strong signal overload from nearby towers. This will keep your booster working without unexpected shutdowns and at maximum efficiency. **SPECIFICATIONS**



Cellular Signal Boosters - Boosting Your Signal Anywhere

Industry Canada