

SUCTION CUP BLUETOOTH® SPEAKER

Operating Instructions

INTRODUCTION


This compact speaker easily connects wirelessly to your music device in seconds—no cable, no hassles! Robust and durable with its unique protective, water-resistant silicone skin, it provides hours of crystal-clear audio on the go. Plus, the clever suction cup stand makes it even easier to listen to your favourite tunes or when paired with your mobile phone. Conduct conference calls anywhere!

WHAT'S INCLUDED:

1. Suction cup Bluetooth® speaker
2. USB to micro-USB charging cable
3. Manual

FEATURES AND FUNCTIONS:

1. Interface dust cover	Protect power switch and micro USB port
2. Power switch	Switch ON/OFF
3. Micro USB	Charging port
4. +	Volume UP/Next
5. -	Volume DOWN/Previous
6. <	Answer/hang up call in Bluetooth® mode
7. Mic	Serves as a microphone during handsfree calls
8. Suction cup	Capable of sticking on any smooth surface
9. LED indicator	Built-in battery indicator



OPERATION:

First, locate the ON/OFF sliding switch found under the dust cover. Slide to the left for ON and back to the right for OFF. The LED light at the base of the speaker will flash and you will hear a sound.

Pairing: This unit will automatically go into pairing mode when it's powered on. Go into your Bluetooth® device settings menu and look for "Gadget8045551". After the unit has paired and connected, it will reconnect automatically when the speaker is powered on and the device is in range.

Use the suction cup at the foot of the speaker to firmly attach the speaker to your device for use as a stand in either vertical or horizontal position. Alternatively, use the suction cup to attach the speaker firmly to any suitable surface (i.e. window, dashboard, desk, etc.). This speaker is water-resistant so it can be used by the pool or the shower. Please note that the speaker cannot be submerged in water.

Important: The LED light will continue to flash under the device when it is switched on. To preserve battery power and ensure uninterrupted fun when out and about, remember to switch off when not in use.

HOW TO USE:

Using your device for handsfree calls when in Bluetooth® mode:

- Use the < button on the side of the speaker (between the volume buttons) to answer a phone call (when in Bluetooth® mode) and then to hang up the call when finished
- Use the < button to redial the last call with a quick double press
- A single press on the + button will forward to the next track. A single press on the - button will switch to the previous track
- Hold the + button to increase the volume
- Hold the - button to decrease the volume
- Alternatively, you can use the volume control on your device to adjust the volume
- Use the mic situated on the side of the speaker during handsfree calls

Note: Sound performance can be affected by transmitting distance, poor signal and other factors. See troubleshooting for more information.

LED Indicator status:

LED light found on the base of the speaker.

Red LED on	Charging
Red LED off	Fully charged
Blue LED flashing quickly	Bluetooth® pairing
Blue LED flashing slowly	Bluetooth® paired successfully

TROUBLESHOOTING:

1. Handsfree call functionality is only available when Bluetooth® device is connected and paired.
2. Handsfree call functionality can be interrupted with interference from time to time, especially with high-frequency electromagnetism.
3. Some terminal audio players manage automatic switching between songs differently and you may experience some POP noise in the interval between songs from time to time.
4. If you experience issues connecting the Bluetooth® device, please delete the Bluetooth® device from the list, reactivate the Bluetooth® speaker, search for the device and re-pair it.
5. Poor signal environments will affect sound playback performance. Moving the speaker to a better signal area will restore performance.
6. Low battery capacity may also affect playback performance. Recharge the device using the cable provided to restore performance.
7. Only the silicone housing is water resistant, allowing use of the speaker outdoors. Please note that the inner structure and components are not waterproof.

SYSTEM SPECIFICATIONS:

Power supply:	DC, 5V
Output power:	3W (1kHz, THD10%)
Frequency:	200Hz-20kHz
Signal/noise ratio:	≥85dB
Impedance:	4 Ohms (Ω)
Li-ion output voltage:	3.7V-4.2V±0.05V
Li-ion input voltage:	5V
Lithium battery capacity:	300mAh
Music play time:	Two hours at maximum volume
Charging time:	<2 hours
Speaker unit:	40mm

INDUSTRY CANADA STATEMENT:

This device complies with RSS-247 of Industry Canada. Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
 - (2) this device must accept any interference, including interference that may cause undesired operation of this device.
- IC:225A-8045551

THE SOURCE – WARRANTY

The Source warrants that this product will be free from defects in materials and workmanship for a period of six (6) months from the date of purchase. Within this period, simply take the product and your proof of purchase to any The Source store or participating dealer and the product will be replaced (where available) without charge. Any product which has been subject to misuse or accidental damage is excluded from this warranty.

This warranty is only applicable to a product purchased through The Source company-owned stores or participating dealers in Canada where the warranty is included with the product. While this warranty does not confer any legal rights other than those set out above, you may have additional statutory rights which will vary under the laws of the various countries, states, provinces and other governmental entities in which The Source operates. This warranty is subject to all statutory rights you may have in Canada.

Imported by:
The Source,
Barrie, Ontario, Canada, L4M 4W5

Manufactured in China

For product support please visit
www.thesource.ca



Please Recycle

© 2016 The Source
All rights reserved.