

Bell

User's manual



Duo Telephone Headset 8061225



Mono Telephone Headset 8061223

Model: 8061223/8061225

Need Help? Call our
customer service number
at 1-866-515-5855

Congratulations


on purchasing your new Bell product. Before using this headset, please read **Important safety instructions**.

This manual has all the feature operations and troubleshooting necessary to install and operate your new Bell headset. Please review this manual thoroughly to ensure proper installation and operation of this innovative and feature-rich Bell product. For support, and customer service call 1-866-515-5855.

The Bell Mono Telephone Headset #108061223 and Bell Duo Telephone Headset #108061225 can be used with any Digital Enhanced Cordless Telecommunications (DECT) phone with a 2.5mm jack. Simply plug the 2.5mm headset jack into the 2.5mm port and use.

Getting started

Please familiarize yourself with the key components of your headset before using.



1. Headrest
2. Adjustable headband
3. Padded earphones
4. Mute switch
5. Volume control
6. 2.5mm jack (plugs into any DECT phone)
7. Bendable microphone arm
8. Microphone
9. 270° vertical microphone arm adjuster

Adjusting the Fit


The Bell Telephone Headset is a highly flexible design that can accommodate most head sizes. Please see the following tips on customizing your fit:

A) The headband is fully adjustable. Pull out and extend the band to create a wider fit. Push in and shorten the headband to create a narrower fit.

B) The microphone arm can rotate up to 270° on both headsets. On the Bell Mono Telephone Headset #108061223, rotate it forwards or backwards to transform the headset to be worn on either ear.



C) The microphone arm rotates from the axis of the earphone and allows for vertical adjustments.


D) The microphone arm is bendable and can be easily shaped to adjust the speaking distance that is comfortable for you and your listener.



Using the In-Line Controller – Microphone Mute Switch



The Microphone Mute Switch creates privacy with a quick switch of the button.

- A) Slide the switch to the  icon to mute what your listener can hear.
- B) Slide the switch to the  icon to return to speaking mode.



Using the In-Line Controller – Volume Control

The Volume Control dial (C) on the side of the in-line controller allows you to adjust the volume according to your preference. Simply dial up or dial down until desired volume is reached.



Bell

Bell is a trademark of Bell Canada.

© 2017, Bell Canada. All rights reserved.

Imported by The Source/Importé par La Source

Barrie, Ontario, Canada, L4M 4W5

Manufactured in China/Fabriqu  en Chine

www.thesource.ca/www.lasource.ca

One year limited warranty, please check with store associate for details.



Please Recycle