

COLOUR CHANGING LED LANTERN

Operating Instructions

Thank you for choosing the Gadgetree Colour Changing LED Lantern. A simple push turns on a brilliant Colour Changing LED light show housed inside a stylish metal lantern with iridescent screen. Cordless and compact, it fits easily into any space from your coffee table to the patio.

Requires 3 AAA batteries (sold separately)

INCLUDED

- One LED lantern

BATTERY INSTALLATION

1. Locate the battery cover on the bottom and using a Phillips head screwdriver, unscrew the cover.
2. Follow the polarity guidelines and place 3 AAA batteries inside the compartment.
3. Replace the battery cover.

GETTING STARTED

1. Place you hand on top of the lantern and push down gently to turn on the LED lights.
2. To turn the lantern off, place you hand on top of the lantern and push down gently.

PUSH



THE SOURCE - WARRANTY



The Source warrants that this product will be free from defects in materials and workmanship for a period of six (6) months from the date of purchase. Within this period, simply take the product and your proof of purchase to any The Source store or participating dealer and the product will be replaced (where available) without charge. Any product which has been subject to misuse or accidental damage is excluded from this warranty. This warranty is only applicable to a product purchased through The Source company-owned stores or participating dealers in Canada where the warranty is included with the product. While this warranty does not confer any legal rights other than those set out above, you may have additional statutory rights which will vary under the laws of the various countries, states, provinces and other governmental entities in which The Source operates. This warranty is subject to all statutory rights you may have in Canada.

Imported by:
The Source,
Barrie, Ontario, Canada, L4M 4W5

Manufactured in China

For product support please visit
www.thesource.ca



Please Recycle

© 2017 The Source
All rights reserved.