


BLUETOOTH® ON-EAR STEREO HEADPHONES HRC 3002

Bluetooth

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth® SIG, Inc. and any use of such marks by The Source (Bell) Electronics Inc. is under license. Other trademarks and trade names are those of their respective owners.

IDENTIFYING THE PARTS OF YOUR HEADPHONES

- 1. ▶ Power/MFB (multi-function button)
- 2. Volume increase +
- 3. Volume decrease -
- 4. LED indicator
- 5. Microphone
- 6. 3.5mm audio jack
- 7. Micro USB charging port



WHAT'S INCLUDED:

Micro USB charging cable 3.5mm audio cable Instruction manual

• HRC 3002 Headphones

INTRODUCTION

Thank you for purchasing HRC 3002 Bluetooth® Headphones. In order to maximize your listening experence, please read the instructions below.

OPERATING INSTRUCTIONS

то	DO THIS
Power ON	Press and hold MFB for 1 second
Power OFF	Press and hold MFB for 5 seconds
Adjust the volume	Press +/- button
Play/Pause	Press MFB once to pause Press again to resume
Next track	Long press + button
Previous track	Long press - button
Answer a call	Press MFB button
End a call	Press MFB button
Reject a call	Press and hold MFB for 1 second
Redial previous number	Double press MFB button

NOTE: The function compatibility may vary among different smartphones or devices. Not all functions are available on all devices.

LED INDICATOR

FUNCTION	LED STATUS
Power ON	Red and blue LED flash once when powered ON. Blue LED flashes continuously
Power OFF	Blue and red LED flash once
Pairing	Red and blue LED flash alternately
Standby	Blue LED flashes every 3 seconds
Incoming call	Blue LED flashes continuously
Low battery	Red LED flashes continuously
Charging	Solid Red LED
Charge complete	Red LED turns OFF when charging is complete

CHARGING

Please charge your headphones fully before the first use. After use, when the battery is low, charge using the included micro USB cable. A full charge will take about 2 hours. During charging, the red LED will remain solid. When fully charged, the red LED will turn OFF.

3.5MM LINE-IN

Insert the supplied audio cable to the headphone socket and the $3.5 \mathrm{mm}$ audio jack into your audio device.

PAIRING

Pairing with one smartphone or other device:

- Make sure the headphones are OFF
- Press and hold the MFB button for 8 seconds to enter into pairing mode
- The red LED and blue LED will flash alternately

- Locate the Bluetooth® settings in your device and search for the headphones
- From the list of found devices, select "HRC 3002" and select to connect to it
- Follow the instructions and enter "0000" as PIN, if required The headphones will automatically connect to your device when switched ON, provided your device Bluetooth® is ON and within range.

USING YOUR HEADPHONES

- 1. For the best sound and comfort, the right fit is very important. Please adjust your headband to make sure the headphones fit snugly and securely.
- Place your headphones on corresponding ear side (R on right ear and L on left ear).
- 3. To ensure your headphones stay in place while doing physical activity, make sure the cord is placed in front of your head and body.

PROTECTING YOUR HEADPHONES

- Keep your headphones clean and free of debris
- Do not tug on the cable to disconnect plug from device but rather pull from the plug to disconnect
- Do not wrap headphones around a device while it is still plugged in as it puts unnecessary pressure on plug/cord connection

SPECIFICATIONS

Bluetooth® version: 4.0

Sound pressure level: 110±5dB
Frequency response: 20Hz-20KHz
Lithium-polymer battery: 3.7V, 400mAh

*HFP=Handsfree profile, HSP=Handset profile, A2DP=Advanced audio distribution profile, AVRCP=Audio video remote control profile.

**Approximate play back time, battery life depends on individual use and may be more or less than specified.

WARNING

- Do not insert plug into electric sockets
- Supervise children when using equipment, this product is not a toy
- Listening to headphones at high volume levels, particularily over extended perions of time may damage your hearing
- If you have a pacemaker or other electrical medical devices, you should consult your physician before using this product
- The operation of switching on your Hi-Fi system or plugging in the headphones may cause clicks which at high volume setting may affect your hearing. Therefore always set the volume control to minimum before switching between different sources (tuner, turntable, CD player, etc) or plugging in the headphones
- DO NOT use the headphones while driving or cycling

TROUBLESHOOTING

No sound

- Power ON the headphones and charge the battery
- Increase the volume on your headphones and Bluetooth® device
- · Make sure you are using the correct paired device
- Move your Bluetooth® device closer to the headphones and away from any interference or obstructions
- Use a different music source
- Pair a different Bluetooth® device

Poor sound quality

- Use a different music source
- Pair a different Bluetooth® device
- Move the Bluetooth® device closer to the headphones, and away from any interference or obstructions

Headphones don't turn ON

- Power ON the headphones
- · Charge the battery

Headphones don't pair with Bluetooth® device

- On your Bluetooth® device: Turn the Bluetooth® feature ON and then OFF. Delete HRC 3002 Headphones from the Bluetooth® list on your device. Pair again
- Move your Bluetooth® device closer to the headphones and away from any interference or obstructions

INDUSTRY CANADA NOTICE RSS247

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions:

(1) this device may not cause interference, and

(2) this device must accept any interference, including interference that may cause undesired operation of the device.

This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus set out in the Radio Interference Regulations of Industry Canada.

IC Number: 255A-8064266

THE SOURCE - WARRANTY



The Source warrants that this product will be free from defects in materials and workmanship for a period of one (1) year from the date of purchase. Within this period, simply take the product and your proof of purchase to any The Source store or participating dealer and the product will be replaced (where available) without charge. Any product which has been subject to misuse or accidental damage is excluded from this warranty.

This warranty is only applicable to a product purchased through The Source company-owned stores or participating dealers in Canada where the warranty is included with the product. While this warranty does not confer any legal rights other than those set out above, you may have additional statutory rights which will vary under the laws of the various countries, states, provinces and other governmental entities in which The Source operates. This warranty is subject to all statutory rights you may have in Canada.

Imported by: The Source, Barrie, Ontario, Canada, L4M 4W5

Manufactured in China

For product support please visit www.headrushaudio.com

© 2017 The Source All rights reserved.

