


WIRELESS ACTIVE NOISE CANCELLING OVER-EAR HEADPHONES HRF 5019

Bluetooth

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth® SIG, Inc. and any use of such marks by The Source (Bell) Electronics Inc. is under license. Other trademarks and trade names are those of their respective owners.

WHAT'S INCLUDED:

- HRF 5019 Headphones
- Micro USB charging cable
- 3.5mm audio cable
- Carry case
- Instruction Manual



IDENTIFYING THE PARTS OF YOUR HEADPHONES

- 1. Micro USB charging port
- 2. Battery level indicator
- 3. 3.5mm audio jack
- 4. NFC connection location
- 5. Noise cancelling
- 6. MFB (Multi-function button)
- 7. Touch screen
- 8. LED

TOUCH SCREEN CONTROLS



Press twice: Play/pause/ answer/reject call

Slide up: Increase volume
Slide down: Decrease volume

Slide forward: Next track
Slide backward: Previous track

INTRODUCTION

Thank you for purchasing the HRF 5019 Headphones. In order to maximize your listening experience, please read the instructions below.

FEATURES

- 1. Noise cancelling (ANC)
- 2. NFC pairing and Qualcomm® aptX™ audio decoding
- 3. Smart touch controls
- 4. Wireless and wired modes

OPERATING INSTRUCTIONS

5. Flip and fold design

PAIRING

Pairing with one smartphone or other device:

- Press and hold the MFB button for 5 seconds to enter into pairing mode
- The red LED and blue LED will flash alternately
- Locate the Bluetooth® settings in your device and search for the headphones
- From the list of found devices, select "HRF 5019" and select to connect to it. The headphones will beep and the blue LED will blink slowly
- Follow the instructions and enter "0000" as PIN, if required
- If you fail to pair a device within 3 minutes the headphones will automatically exit pairing mode

PAIRING WITH TWO SMARTPHONES OR OTHER DEVICES

The headphones can support a multi-connection. They can pair with two devices simultaneously and can take a call from either one.

- After pairing is complete with the first device, turn the headphones OFF. Then, repeat the pairing procedure with the second device
- Once it's connected with the device, go back to the previous device to turn on the Bluetooth® and select HRF 5019 to connect to it

NOTE: When two smartphones have different operating systems, (eg one has Android $^{\text{TM}}$ and the other is iOS $^{\text{®}}$) some cross-system operations (Pause songs in Android $^{\text{TM}}$ play songs on iOS $^{\text{®}}$) may experience delays. Please be aware that this is normal. The headphones will automatically connect to your device when switched ON, provided your Bluetooth $^{\text{®}}$ is ON and within range.

FUNCTION	OPERATION	LED
Power ON	Press and hold MFB for 3 seconds	Blue LED will flash once
Power OFF	Press and hold MFB for 3 seconds	Red LED will flash once
Turn noise cancelling ON	Slide switch to ON	
Turn noise cancelling Off	Slide switch to OFF	

CHARGING Please charg

Please charge your headphones fully before the first use. After use, when the battery is low, charge using the included micro USB cable. The charging LED will turn solid red when charging, and then turn OFF when fully charged. When the battery is low the Battery Level LED will turn red and the headphones will beep. The battery will take approximately 4 hours to fully charge.

BATTERY CAPACITY STATUS

When the headphones are connected to an iOS® device, the headphone battery status will appear in the upper right-hand corner. When the battery icon is red, please charge the headphones.





NFC CONNECTION

- For initial pairing using the NFC feature the headphones have to be put into pairing mode. Please ensure your Bluetooth® device supports NFC and that the function is ON
- With the headphones in pairing mode hold your Bluetooth® device over the NFC logo on the headphones and they will



- automatically connect and the headphones will beep
- The headphones will now automatically connect to the Bluetooth® device each time they are turned ON. Once the headphones have been paired they can be unpaired and repaired by holding your Bluetooth® device over the NFC logo when both the headphones and Bluetooth® device are ON

OPERATION

то	DO THIS
Power ON	Press and hold MFB button for 3 seconds.
Power OFF	Press and hold MFB button for 3 seconds.
Answer/end a call	Press screen twice.
Reject incoming call	Press and hold touch screen for 2 seconds.
Increase volume	Swipe up on touch screen.
Decrease volume	Swipe down on touch screen.
Transfer call to smart phone	Press and hold touch screen for 2 seconds.
Transfer call to headphones	Press and hold touch screen for 2 seconds.
Redial	press MFB twice.
Voice Dial	Press and hold MFB for 2 seconds.
End current call to answer new incoming call	Press MFB once.
Remain on the current call and answer incoming call	Press MFB twice.
Switch between calls	Press MFB twice.
Play/Pause	Press touch screen twice to pause. Press twice to resume.
Next track	Swipe forward quickly on touch screen.
Previous track	Swipe backward quickly on touch screen.

MAKE A THREE WAY CALL

то	DO THIS
End current call to answer incoming call	Press MFB button once.
Place current call on hold and answer incoming call	Press MFB button twice.
Switch between calls	Double press MFB button.
End current call	Press MFB button once.

3.5MM LINE-IN

Insert the supplied audio cable to the headphone socket and the 3.5mm audio jack into your audio device.

NOTE: When listening to music via the 3.5mm line in the Bluetooth® connection will turn OFF.

USING YOUR HEADPHONES

- 1. For the best sound and comfort, the right fit is very important. Please adjust your headband to make sure the headphones fit snugly and securely.
- Place your headphone on corresponding ear side ("R" on right ear and "L" on left ear).
- 3. To ensure your headphones stay in place while doing physical activity, make sure the cord is placed in front of your head and body.

PROTECTING YOUR HEADPHONES

- Keep your headphones clean and free of debris
- Do not tug on the cable to disconnect plug from device but rather pull from the plug to disconnect
- Do not wrap headphones around a device while it is still plugged in as it puts unnecessary pressure on plug/cord connection

FOLDING AND STORING YOUR HEADPHONES

 Rotate the ear cups inwards, then place the headphones in the carry case

NOTE: The ear cups rotate only in one direction. Incorrectly rotating the earcups can damage the headphones.

WARNING

- Do not insert plug into electric sockets
- Supervise children when using equipment, this product is not a toy
- Listening to headphones at high volume levels, particularily over extended periods of time, may damage your hearing

- If you have a pace maker or other electrical medical devices, you should consult your physician before using this product
- The operation of switching on your Hi-Fi system or plugging in the headphones may cause clicks which at high volume setting may affect your hearing. Therefore always set the volume control to minimum before switching between different sources (tuner, turntable, CD player, etc) or plugging in the headphones
- DO NOT use the headphones while driving or cycling
- The small parts included with this product can be a choking hazard. This product is not intended for use by small children and should be kept away from children under 3 years of age

TROUBLESHOOTING

No sound

- Power ON the headphones and charge the battery
- Increase the volume on your headphones and Bluetooth® device
- Make sure you are using the correct paired device
- Move your Bluetooth® device closer to the headphones and away from any interference or obstructions
- Use a different music source
- Pair a different Bluetooth® device
- If two Bluetooth® devices are connected, pause the first device and play the other device
- If two Bluetooth® devices are connected, move the devices within range of the headphones

Poor call quality

• Ensure you have adequate cellular signal

Poor sound quality

- Use a different music source
- Pair a different Bluetooth® device
- Disconnect the second device
- Move the Bluetooth® device closer to the headphones, and away from any interference or obstructions

Unable to pair using NFC

- Ensure NFC has been enabled on your mobile device
- Allow mobile phone to touch the headphones for about 3 seconds, then remove headphones until the red and blue LED blink alternately

IMPORTANT SAFETY INFORMATION CAUTIONS

- Keep in a safe place free from dust, liquid and extreme temperatures
- Do not attempt to disassemble the product
- Do not use chemicals to clean the product

SPECIFICATIONS

Bluetooth® version: 4.1

Bluetooth® profiles A2DP/AVRCP/HSP/HFP*
Talk time Approx. 25 hours**
Stand-by time Approx. 1500 hours**
Music play time Approx. 25 hours**
Wireless range within 10m (32 ft.)

 $\begin{array}{lll} \text{Driver diameter} & 40\text{mm} \\ \text{Impedance} & 32\Omega \\ \text{Sound pressure level} & 97\text{dB} \\ \text{Frequency response} & 20\text{Hz-}20\text{KHz} \\ \end{array}$

Battery 1500mAh Polymer lithium

Recharging input DC 5V, 1A

*HFP = Handsfree profile, HSP= Handset profile, A2DP=Advanced audio distribution profile, AVRCP=Audio/video remote control profile.

**Approximate playback time, battery life depends on individual use and may be more or less than specified.

Industry Canada Notice

This device complies with RSS-247 of Industry Canada. Operation is subject to the following two conditions:

(1) this device may not cause interference, and

(2) this device must accept any interference, including interference that may cause undesired operation of the device.

This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus set out in the Radio Interference Regulations of Industry Canada.

IC NUMBERS: 255A-8073878

THE SOURCE - WARRANTY



The Source warrants that this product will be free from defects in materials and workmanship for a period of 12 months from the date of purchase. Within this period, simply take the product and your proof of purchase to any The Source store or participating dealer and the product will be replaced (where available) without charge. Any product which has been subject to misuse or accidental damage is excluded from this warranty.

This warranty is only applicable to a product purchased through The Source company-owned stores or participating dealers in Canada where the warranty is included with the product. While this warranty does not confer any legal rights other than those set out above, you may have additional statutory rights which will vary under the laws of the various countries, states, provinces and other governmental entities in which The Source operates. This warranty is subject to all statutory rights you may have in Canada.

Imported by: The Source, Barrie, Ontario, Canada, L4M 4W5