

WIRELESS SPEAKER

TITAN HRSP 5006

Bluetooth

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth® SIG, Inc. and any use of such marks by The Source (Bell) Electronics Inc. is under license. Other trademarks and trade names are those of their respective owners.

WHAT'S INCLUDED:

- Speaker
- Micro USB charging cable
- 3.5mm audio cable
- Carabiner
- Instruction Manual

0

COMPONENT IDENTIFICATION

- NFC connection location
- Volume down/Previous Track -
- Volume up/Next track +
- 4. Call &
- Power ON/OFF 6
- Play/Pause №
- 1/4"-20 screw mount
- (accessories sold separately)
- USB charging port
- Aux in
- 10. Reset

PRODUCT OVERVIEW

You can use this item with iPad®, iPhone®, iPod® devices and many types of smartphones to stream music, and enjoy handsfree calling. In order to get the best results when using this device, please read this manual first before using. This unit has IP65 rating: Dust tight, protected against jetting water. Do not submerge in water.

PAIRING

- Make sure your Bluetooth® audio source is held within 10 metres of your speaker.

 Press and hold the Power ON/OFF button until you hear a beep. The blue LED will flash.

 Enable your Bluetooth® device, and make sure it is in searching mode.

 Select "HR Titan" from the list of discovered Bluetooth® devices on your smartphone.

 Once paired, the speaker will beep and the blue LED will stay ON.
- You can now listen to your music or make/receive telephone calls on the speaker. While playing music, to increase or decrease the volume, long press the + or button. To
- change to previous/next song, short press the + or button.

 7. To turn the speaker OFF hold the Power ON/OFF button, you will hear a short beep.

 Tip: The next time when you switch the speaker ON it will connect automatically as long as your Bluetooth® function is switched ON on your audio device. The speaker will beep.

 When you disconnect the speaker while paired, the blue LED light will start to blink, the speaker has entered into pairing mode. If there is no device paired within 15 minutes the speaker will turn OFF.

PAIRING BY ONE-TOUCH CONNECTION WITH NFC

- Enable the NFC function on your device.
- Use your NFC-enabled device and touch the NFC logo on the speaker.

 Confirm the NFC connection on your device. This will vary depending on your device, check your device manual for compatibility.
- 4. The speaker will beep when pairing is successful.

CHARGING

speaker will turn OFF.

This speaker has a built-in rechargeable Li-Ion battery. Fully charge the speaker before first use. Charge the battery as follows:

- 1. Connect one end of the included USB charging cable to the charging port on your speaker. Then plug the other end of the USB charging cable into a suitable port on your computer or 5V/1A power adapter (sold separately).

 The red LED light will turn ON. When the charge is complete the red LED light will turn
- It will take approximately 6 hours to fully charge the speaker by 5V/1A power adapter (sold separately).

Tip: When battery is low the speaker will beep every 30 seconds. Charge the speaker.

HANDSFREE SPEAKERPHONE

When a smartphone is connected to your speaker follow the steps below to take calls handsfree. 1. If there is an incoming call while streaming music, the speaker will beep to notify the call.
2. Short press the P button to pick up the call.
3. Short press the P again to hang up the call.
4. Long press the P button to reject the call.

1. Use the supplied 3.5mm cable to connect the speaker directly with your device. **Tip:** AUX-IN will take priority.

TO PLAY MUSIC FROM YOUR PC OR LAPTOP

After pairing the device to your PC or laptop, right-click on the speaker icon on the lower right hand corner of the task bar, select "Playback devices". Under the "Playback" tab, the paired device will show within the list. To connect it, click on the device to set it as the default device. The audio will start to play from the paired device.

UNDERSTANDING THE LED STATUS LIGHTS

- When charging your speaker
 o Solid red LED=charging
 o Red LED OFF=charging complete
- When pairing your speaker to a Bluetooth® device
 o Blinking blue LED=Bluetooth® not connected, ready to pair
- o Solid blue LED=Bluetooth® connected When connected via AUX-IN
- o Solid blue LED=connected

TECHNICAL SPECIFICATIONS

Bluetooth® Version: V4.1 7.4V, 2600mAh Battery Capacity: Frequency Response: Operation Distance: 100Hz-20kHz Up to 10 metres (33 ft.) 2 x 5W (Max.) Output Power:

4 Ohms

NOTE: This speaker is in compliance with the specified Bluetooth® version. It does not guarantee compatibility with all the functions on every Bluetooth® enabled device. Please check your smartphone's user manual for compatibility and functionality

TROUBLESHOOTING

No Sound

Impedance:

- Ensure the speaker is charged and has enough battery power for operation
- Ensure the speaker is switched ON Ensure Bluetooth® device is ON
- The volume of the speaker is too low, adjust the volume to an appropriate level

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

THE FCC WANTS YOU TO KNOW

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference and
- (2) this device must accept any interference received, including interference that might cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Industry Canada Notice

This device complies with RSS-247 of Industry Canada. Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus set out in the Radio Interference Regulations of Industry Canada.

IC NUMBERS: 255A-8074115

THE SOURCE - WARRANTY



The Source warrants that this product will be free from defects in materials and workmanship for a period of 12 months from the date of purchase. Within this period, simply take the product and your proof of purchase to any The Source store or participating dealer and the product will be replaced (where available) without charge. Any product which has been subject to misuse or accidental damage is excluded from this upgraph.

twister available, without mage. Any product which has been sobject to missis of decidental damage is excluded from this warranty. This warranty is only applicable to a product purchased through The Source company-owned stores or rinis warranty is only applicable to a product purchased through the source company-wheel soldres participating dealers in Canada where the warranty is included with the product. While this warranty does not confer any legal rights other than those set out above, you may have additional statutory rights which will vary under the laws of the various countries, states, provinces and other governmental entities in which The Source operates. This warranty is subject to all statutory rights you may have in

Imported by:

The Source, Barrie, Ontario, Canada, L4M 4W5

www.headrushaudio.com

