LED NEON LIGHT 8075286/8

Instruction Manual

## **INCLUDED**

- Battery-operated neon light
- · Instruction Manual

## GETTING STARTED OPERATING INSTRUCTIONS:

- 1. Carefully remove neon light from packaging
- 2. Open the battery box cover located at base of the neon light.
- Insert 3 AA batteries (not included) following the polarity (+/-) marked. (Do not mix old and new batteries; do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries).
- 4. Close battery box cover.
- 5. Turn the light ON.

## **WARNINGS:**

- Neon Light is for indoor use only
- Lights are not waterproof, please use in dry and clean place
- **DO NOT** install batteries while the product is in the packaging
- · Remove batteries when not in use
- **DO NOT** use outdoors
- **DO NOT** use if product is damaged
- DO NOT expose to direct heat, flame or immerse in water
- Protect product from sharp or potentially damaging objects to avoid damage to the Neon Light



## THE SOURCE - WARRANTY

The Source warrants that this product will be free from defects in materials and workmanship for a period of 6 months from the date of purchase. Within this period, simply take the product and your proof of purchase to any The Source store or participating dealer and the product will be replaced (where available) without charge. Any product which has been subject to misuse or accidental damage is excluded from this warranty. This warranty is only applicable to a product purchased through The Source company-owned stores or participating dealers in Canada where the warranty is included with the product. While this warranty does not confer any legal rights other than those set out above, you may have additional statutory rights which will vary under the laws of the various countries, states, provinces and other governmental entities in which The Source operates. This warranty is subject to all statutory rights you may have in Canada.

