


INCLUDED

- Dancing Water Speakers
- 3.5mm audio cable
- USB power cable
- Instruction manual

GETTING STARTED

OPERATING INSTRUCTIONS

Turn the volume to minimum before connecting.



- Connect the left speaker to the right using the connect cable
- Plug the left speaker into a computer or 500mA or higher AC adapter (not included) using the included USB power cable
- Connect the left speaker and your device using the supplied 3.5mm audio cable
- Press play and adjust the volume on your device to enjoy the light and dancing water show

NOTE: The speakers do not have a separate volume control. The louder your music, the more powerful the dancing jets of water.

WARNING:

If you experience dizziness, altered vision, eye or muscle twitches or disorientation at any time while using the product discontinue use and seek medical advice.

SPECIAL CARE AND HANDLING

- Handle with care
- DO NOT expose to moisture or extreme temperatures. For best results, use between the temperatures 4°C and 38°C
- DO NOT clean with chemical solvents. Use only a clean, dry cloth

THE FCC WANTS YOU TO KNOW

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for additional suggestions

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Where shielded interface cables have been provided with the product or specified additional components or accessories elsewhere defined to be used with the installation of the product, they must be used in order to ensure compliance with FCC regulation.

CAN ICES-3(B)/NMB-3(B)

THE SOURCE - WARRANTY

The Source warrants that this product will be free from defects in materials and workmanship for a period of 6 months from the date of purchase. Within this period, simply take the product and your proof of purchase to any The Source store or participating dealer and the product will be replaced (where available) without charge. Any product which has been subject to misuse or accidental damage is excluded from this warranty. This warranty is only applicable to a product purchased through The Source company-owned stores or participating dealers in Canada where the warranty is included with the product. While this warranty does not confer any legal rights other than those set out above, you may have additional statutory rights which will vary under the laws of the various countries, states, provinces and other governmental entities in which The Source operates. This warranty is subject to all statutory rights you may have in Canada.

Imported by:
The Source, Barrie, Ontario, Canada, L4M 4W5
Manufactured in China
www.thesource.ca
© 2018 The Source All rights reserved.

