#### **SMARTPHONE TRIPOD WITH REMOTE**

Instruction Manual


#### INCLUDED

- Tripod
- · Smartphone holder
- Remote
- · Instruction manual



## GETTING STARTED OPERATING INSTRUCTIONS

 Insert the included battery into the remote with the positive (+) side up.



- 2. Screw the smartphone holder to the tripod.
- 3. Secure the smartphone in the holder.
- 4. Rotate smartphone to the desired angle. Tighten the screw to secure.
- 5. Tripod legs are flexible and can wrap around furniture, poles, etc. for the perfect image or video.
- 6. Use the remote to take a still photo or to start and stop a video.
- 7. Put your smartphone in photo or video mode.
- 8. Use the remote to take a photo or to start and stop a video.
  Button A is for iOS devices and Button B is for Android™ devices.

#### PAIRING THE REMOTE

- Press the ON/OFF button on the remote to enter pairing mode. The LED will flash
- Turn the Bluetooth® ON in your device settings and select "8075872"
- Device will pair automatically

#### **SPECIFICATIONS**

Bluetooth® V3.0 Bluetooth range® 10m (33 ft.)

Compatibility Android 4.2.2 or newer and iOS 6.0 or newer

Remote battery type CR2032 button cell (included)

Fits phones: up to 3-3/8" wide

# **Bluetooth**\*

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth® SIG, Inc. and any use of such marks by The Source (Bell) Electronics Inc. is under license. Other trademarks and trade names are those of their respective owners.

#### **BATTERY DISCLAIMER**

**WARNING:** Keep out of reach of children. If swallowed call your doctor immediately. DO NOT open battery, dispose of in fire, charge, install backwards or mix with used or other battery.

#### **INDUSTRY CANADA NOTICE RSS247**

This device complies with Industry Canada license-exempt RSS standard(s).

Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus set out in the Radio Interference Regulations of Industry Canada.

IC NUMBER: 255A-8075872



### THE SOURCE - WARRANTY

The Source warrants that this product will be free from defects in materials and workmanship for a period of (6) six months from the date of purchase. Within this period, simply take the product and your proof of purchase to any The Source store or participating dealer and the product will be replaced (where available) without charge. Any product which has been subject to misuse or accidental damage is excluded from this warranty.

This warranty is only applicable to a product purchased through The Source company-owned stores or participating dealers in Canada where the warranty is included with the product. While this warranty does not confer any legal rights other than those set out above, you may have additional statutory rights which will vary under the laws of the various countries, states, provinces and other governmental entities in which The Source operates. This warranty is subject to all statutory rights you may have in Canada.

