

INSTRUCTION MANUAL—

8078357

Please read this manual carefully and retain for future reference.

INCLUDED


- Wireless Bluetooth® keyboard
- 2 AAA batteries
- Instruction manual

FEATURES

- Bluetooth® 3.0 compatible
- Compatible with most Bluetooth®-enabled devices
- 78-key scissor low-profile design
- Built-in intelligent power management software for power conservation

INSTALLING THE BATTERIES



1. Open the battery compartment on the back of the keyboard.
2. Insert 2 AAA batteries following the polarity (+/-) marked.
3. Close the battery compartment.



GETTING STARTED

PAIRING

1. Turn the keyboard ON.
2. Press the **CONNECT** button.
3. Go to the Bluetooth® settings on your device, select “8078357”, then click **NEXT**.
4. Input the password shown on your device using the Bluetooth® keyboard then hit **ENTER**
5. Click **NEXT** on your device if required.
6. The keyboard will now pair automatically provided the Bluetooth® is ON and within range.



CONNECTING:
Flashing Blue LED light
POWER LOW:
Flashing Blue LED light

When Caps-lock is ON, the LED indicator will be green.

POWER SAVING MODE

The keyboard will enter a power saving sleep mode after 10 minutes of inactivity. Press any key to exit sleep mode.

LOW POWER INDICATOR

The LED indicator will flash BLUE when the battery power is low. Replace both batteries to prevent power interruption. The LED indicator will be green when CAPS LOCK is ON

KEYBOARD [Fn] FUNCTION LIST

Before using the Fn function, please select the type of Bluetooth® device that is paired with this Bluetooth® keyboard.

Fn + Q	=	Android™ OS
Fn + W	=	Windows OS
Fn + E	=	Apple iOS
Fn + arrow up	=	Page up
Fn + arrow down	=	Page down
Fn + arrow left (home)	=	Back to the front page
Fn + arrow right (end)	=	Go to the last page

WINDOWS

- Fn+ESC= Web home
- Fn+F1 = Cut
- Fn+F2 = Copy
- Fn+F3 = Paste
- Fn+F4 = Auto language switch
- Fn+F5 = Search
- Fn+F6 = Previous track
- Fn+F7 = Play/Pause
- Fn+F8 = Next track
- Fn+F9 = Mute
- Fn+F10 = Volume down
- Fn+F11 = Volume up
- Fn+F12 = Shut down the computer

iOS AND ANDROID™

- ESC = Main page
- F1 = Cut
- F2 = Copy
- F3 = Paste
- F4 = Auto language switch
- F5 = Search
- F6 = Previous track
- F7 = Play/Pause
- F8 = Next track
- F9 = Mute
- F10 = Volume down
- F11 = Volume up
- F12 = Screen lock

NOTE: You must press and hold the **[Fn]** key to activate the desired key function.

TROUBLESHOOTING

If you are experiencing connection issues please follow the steps below:

- Ensure Bluetooth® is ON and within range
- Press and release the CONNECT button to enter pairing mode
- Check batteries and replace if necessary

SPECIFICATIONS

Bluetooth® version: 3.0

Bluetooth® range: up to 10m (33 ft.)

Compatibility: Windows 7/8/10; Mac OSX 10.10; Android™ 4.4; iOS 9.0 and above

NOTE: Function [Fn] keys are not compatible with Mac OS X

Requires: 2 AAA batteries (included)



The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth® SIG, Inc. and any use of such marks by The Source (Bell) Electronics Inc. is under license. Other trademarks and trade names are those of their respective owners.

INDUSTRY CANADA NOTICE RSS247

This device complies with Industry Canada license-exempt RSS standard(s).

Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus set out in the Radio Interference Regulations of Industry Canada.

IC NUMBER: 255A-8078357



THE SOURCE - WARRANTY

The Source warrants that this product will be free from defects in materials and workmanship for a period of 12 months from the date of purchase. Within this period, simply take the product and your proof of purchase to any The Source store or participating dealer and the product will be replaced (where available) without charge. Any product which has been subject to misuse or accidental damage is excluded from this warranty.

This warranty is only applicable to a product purchased through The Source company-owned stores or participating dealers in Canada where the warranty is included with the product. While this warranty does not confer any legal rights other than those set out above, you may have additional statutory rights which will vary under the laws of the various countries, states, provinces and other governmental entities in which The Source operates. This warranty is subject to all statutory rights you may have in Canada.

Imported by:
The Source, Barrie, Ontario, Canada, L4M 4W5
Manufactured in China
© 2018 The Source All rights reserved.
www.thesource.ca

