3-PACK LED PILLAR CANDLES

Instruction Manual

INCLUDED


- 3 LED Pillar Candles
- Remote control
- Instruction manual

GETTING STARTED BATTERY INSTALLATION-CANDLES

- 1. Open the battery compartment.
- 2. Insert 3 AAA alkaline batteries (sold separately) into each candle following the polarity (+/-) marked.
- 3. Close the battery compartment.

BATTERY INSTALLATION-REMOTE

- 1. Open the battery compartment.
- 2. Insert a CR2025 battery (included) with the (+) facing up.
- 3. Close the battery compartment.



CARE AND MAINTENANCE

Clean with a soft dry cloth

WARNINGS

- Keep away from children
- FLAMMABLE, keep away from any heat source that could cause the wax to soften, melt or catch fire
- For indoor use only
- Keep batteries out of reach of children
- Never dispose of used batteries in an open fire.
- Do not mix different kind of batteries or old and used batteries together.
- Batteries may explode or leak.


BATTERY DISCLAIMER

WARNING: Keep out of reach of children. If swallowed call your doctor immediately. DO NOT open battery, dispose of in fire, charge, install backwards or mix with used or other battery types. May explode or leak and cause personal injury.

OPERATING INSTRUCTIONS-REMOTE

- 1. Turn the candles ON or OFF.
- 2. TIMER: Press 2H, 4H, 6H, 8H, to select desired time. Once the time is set, the candle will turn ON and OFF at the same time each day for the length of time selected. Timer will reset after the candle is turned OFF manually using the switch on the bottom.
- 3. MODE: Select cable for a flickering light or light for a steady light.
- 4. DIMMER: Use the dimmer buttons to adjust the brightness of the candle.

NOTE: Always turn the candle OFF when not in use and remove batteries if the candle will not be used for an extended period of time.





THE SOURCE - WARRANTY

The Source warrants that this product will be free from defects in materials and workmanship for a period of 12 months from the date of purchase. Within this period, simply take the product and your proof of purchase to any The Source store or participating dealer and the product will be replaced (where available) without charge. Any product which has been subject to misuse or accidental damage is excluded from this warranty. This warranty is only applicable to a product purchased through The Source company-owner stores or participating dealers in Canada where the warranty is included with the product. While this warranty does not confer any legal rights other than those set out above, you may have additional statutory rights which will vary under the laws of the various countries, states, provinces and other governmental entities in which The Source operates. This warranty is subject to all statutory rights you may have in Canada.

