

# COB LED LANTERN

8085216

Instruction Manual

## INCLUDED

- LED Lantern
- Instruction manual

## GETTING STARTED

### INSERTING THE BATTERIES

- Turn the battery cover, located on the bottom of the lantern
- Insert 3 AAA batteries (sold separately) following the polarity (+/-) marked
- Replace the battery cover and turn to close

**NOTE:** Only use batteries specified and DO NOT use rechargeable batteries.

## OPERATING INSTRUCTIONS

- Pull up on handles to turn the lantern ON
- Open the lantern more to increase lighting scope
- Can be set on a table top or hung by the handles

## BATTERY WARNINGS

- Batteries should be removed and replaced by adults only. Keep away from children
- **DO NOT** mix old and new batteries
- **DO NOT** mix alkaline, standard (carbon-zinc) or rechargeable (Ni-Cd, Ni-MH, etc.) batteries
- To avoid explosion or leakage, do not dispose of batteries in a fire or attempt to charge standard or alkaline batteries (non-rechargeable batteries)
- Remove batteries and store them in a cool, dry place when not in use for a long period
- Always remove exhausted or dead batteries from the product.
- Do dispose of batteries per the local law and regulations of your region. Some batteries may be recycled and may be accepted for disposal at your local recycling centre

## WARNING

- **DO NOT** shine light directly into eyes