


INCLUDES

- Clip-on book light
- Instruction manual

PRODUCT IDENTIFICATION



1. LED light
2. ON/OFF button
3. Flexible neck
4. Adjustable clip

GETTING STARTED

BATTERY INSTALLATION

- Slide open the battery compartment cover located under the base of the unit
- Insert 3 AAA batteries (sold separately) following the polarity marks as shown inside the compartment
- Replace the cover

OPERATION

- Press down on the back of the clip to attach the light to any surface
- Adjust the flexible neck of the LED light into the desired position to direct light where needed
- Press the ON/OFF button once to turn the light ON
- Press the ON/OFF button again to adjust the brightness of the light— it will cycle through high, medium and low levels
- Press the ON/OFF button a final time to turn the light OFF

 **THE SOURCE - WARRANTY**

The Source warrants that this product will be free from defects in materials and workmanship for a period of 6 months from the date of purchase. Within this period, simply take the product and your proof of purchase to any The Source store or participating dealer and the product will be replaced (where available) without charge. Any product which has been subject to misuse or accidental damage is excluded from this warranty. This warranty is only applicable to a product purchased through The Source company-owned stores or participating dealers in Canada where the warranty is included with the product. While this warranty does not confer any legal rights other than those set out above, you may have additional statutory rights which will vary under the laws of the various countries, states, provinces and other governmental entities in which The Source operates. This warranty is subject to all statutory rights you may have in Canada.

Imported by:
The Source, Barrie, Ontario, Canada, L4M 4W5
Manufactured in China
www.thesource.ca
© 2021 The Source All rights reserved.

