

# LIGHT-UP WORD CLOCK

Instruction Manual

8087959

## INCLUDED

- Light-up word clock
- USB cable
- Instruction manual

## FEATURES

1. Displays words to tell the time.
2. LED lights up a new word every five minutes.

## GETTING STARTED

### BATTERY INSTALLATION

1. Slide to remove the battery cover.
2. Insert 3 AA batteries (sold separately) and align them with the correct polarities (+ / -).
3. Replace the battery cover.

**NOTE:** Alkaline batteries are recommended. **DO NOT** mix old and new batteries. **DO NOT** mix alkaline, standard and rechargeable batteries.

### USB POWERED

1. Insert the included USB cable into the clock and plug into a wall adapter or alternative power source (sold separately).

## OPERATING INSTRUCTIONS

### SETTING THE TIME

1. Switch the ON/OFF switch into the ON position.
2. Press + or - to adjust the time. It's best to wait until the time is an interval of 0 or 5 to get the most accurate time possible.

**NOTE: DO NOT** turn the clock OFF or the time will reset.

## CARE AND MAINTENANCE

- Keep your clock away from direct sunlight, excessive heat or moisture
- Lay down a cloth or protective material underneath the clock to protect furniture surfaces that are natural wood with a lacquered finish
- Clean your clock with a soft cloth moistened with mild soap and water
- If you don't use this clock for a month or more, remove the batteries to prevent possible corrosion. If the battery compartment becomes corroded or dirty, clean the compartment and replace the batteries

## WARNING

- Danger of explosion if the batteries are incorrectly replaced. Only replace batteries with the same or equivalent type
- Ensure the correct battery polarity is followed, as an improperly installed battery may cause damage to the clock
- **DO NOT** mix old and new batteries
- **DO NOT** mix alkaline, standard and rechargeable batteries

## CAN ICES-003(B) / NMB-003(B)



## THE SOURCE - WARRANTY

The Source warrants that this product will be free from defects in materials and workmanship for a period of six (6) months from the date of purchase. Within this period, simply take the product and your proof of purchase to any The Source store or participating dealer and the product will be replaced (where available) without charge. Any product which has been subject to misuse or accidental damage is excluded from this warranty.

This warranty is only applicable to a product purchased through The Source company-owned stores or participating dealers in Canada where the warranty is included with the product. While this warranty does not confer any legal rights other than those set out above, you may have additional statutory rights which will vary under the laws of the various countries, states, provinces and other governmental entities in which The Source operates. This warranty is subject to all statutory rights you may have in Canada.

Imported by:  
The Source, Barrie, Ontario, Canada, L4M 4W5  
Manufactured in China  
www.thesource.ca  
© 2020 The Source. All rights reserved.

