FLEXIBLE SMARTPHONE TRIPOD WITH REMOTE

Instruction Manual

INCLUDED

- Flexible tripod
- Phone holder
- Bluetooth® remote
- · Instruction manual



FEATURES:

- Tripod legs have silicone finish to secure to surfaces
- Durable legs, each joint with affixed screws for added stability
- Includes universal GM 1/4" screw on tripod can be used to also fit camera and action cameras



GETTING STARTED OPERATING INSTRUCTIONS

- 1. Remove the battery insulation tab from the remote before use.
- 2. Screw the smartphone holder to the tripod.
- 3. Secure the smartphone in the holder.
- 4. Rotate smartphone to the desired angle. Tighten the screw to secure.
- 5. Tripod legs are flexible and can wrap around furniture, poles, etc. for the perfect image or video.
- 6. Put your smartphone in photo or video mode.
- Use the shutter button on the remote to take a photo or to start and stop a video.

NOTE: To replace the battery in the remote, insert a new battery (sold separately) into the remote with the positive (+) side up.

PAIRING THE REMOTE

- Press the ON/OFF button on the remote to enter pairing mode.
 The LED will flash
- Turn the Bluetooth® ON in your device settings and select "8092932"
- Device will pair automatically

Bluetooth* remote control cannot be used for cameras. Only for smartphones or other smart devices with Bluetooth* function.

SPECIFICATIONS

Bluetooth V5.0 Bluetooth range 10m (33 ft.)

Compatibility Android™ 8.0 or newer and iOS 11 or newer

Remote battery type CR2032 button cell (included)

Fits phones: up to 3-3/8" wide

Bluetooth

The Bluetooth* word mark and logos are registered trademarks owned by Bluetooth* SIG, Inc. and any use of such marks by The Source (Bell) Electronics Inc. is under license. Other trademarks and trade names are those of their respective owners.

BATTERY DISCLAIMER

WARNING: Keep out of reach of children. If swallowed call your doctor immediately. DO NOT open battery, dispose of in fire, charge, install backwards or mix with used or other battery.

INDUSTRY CANADA NOTICE RSS247

This device complies with Industry Canada license-exempt RSS standard(s).

Operation is subject to the following two conditions:

(1) this device may not cause interference, and

(2) this device must accept any interference, including interference that may cause undesired operation of the device.

This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus set out in the Radio Interference Regulations of Industry Canada.

IC: 255A-8092932



THE SOURCE - WARRANTY

The Source warrants that this product will be free from defects in materials and workmanship for a period of (6) six months from the date of purchase. Within this period, simply take the product and your proof of purchase to any The Source store or participating dealer and the product will be replaced (where available) without charge. Any product which has been subject to misuse or accidental damage is excluded from this purchase to any The Source store or participating dealer and the product will be replaced (where available) without charge. Any product which has been subject to misuse or accidental damage is excluded from the purchase to any The Source store or participating dealer and the product will be replaced (where available) without charge.

This warranty is only applicable to a product purchased through The Source company-owned stores or participating dealers in Canada where the warranty is included with the product. While this warranty does not confer any legal rights other than those set out above, you may have additional statutory rights which will vary under the laws of the various countries, states, provinces and other governmental entities in which The Source operates. This warranty is subject to all statutory rights you may have in Canada.

