Before installing and using this product, please read the instructions thoroughly and retain them for future reference.

WHAT'S INCLUDED

- Wireless mouse
- 2 AA Vital batteries
- Nano USB receiver
- Instruction manual

SETUP


 Open the battery compartment, remove the paper tab and USB receiver. Insert the batteries following the polarity (+/-) marked.




2. Turn the mouse ON.



3. Insert USB receiver into a USB port on your computer. Wait up to 1 minute. Your mouse is now ready to use.



COMPONENT IDENTIFICATION



CHANGING THE BATTERY

- · Open the battery cover
- Insert 2 AA batteries (included) following the polarity (+/-) marked

ADJUST THE DPI (TRACKING SPEED)

- Press the DPI up and down buttons to adjust the mouse's sensitivity (tracking speed). The higher the number, the faster the tracking speed
- DPI options are 800, 1200, 1600, 2400

NOTE

- On some surfaces the use of a mouse pad may be necessary
- Turn the mouse OFF when travelling or not in use for long periods to conserve battery life

SYSTEM REQUIREMENTS

- Windows 7/8/10/11, Mac OS X® 10.10 or higher
- USB 2.0 port

SPECIFICATIONS

Frequency: 2.4GHz

Operating distance: Up to 8m (26ft.)

DPI: 800/1200/1600/2400

INDUSTRY CANADA RSS 210

This device complies with RSS-210 of Industry Canada. Operation is subject to the following two conditions:

- 1. this device may not cause interference, and
- 2. this device must accept any interference, including interference that may cause undesired operation of the device.

This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus set out in the Radio Interference Regulations of Industry Canada.

IC: 255A-8093168



THE SOURCE - WARRANTY

The Source warrants that this product will be free from defects in materials and workmanship for a period of twelve (12) months from the date of purchase. Within this period, simply take the product and your proof of purchase to any The Source store or participating dealer and the product will be replaced (where available) without charge. Any product which has been subject to misuse or accidental damage is excluded from this warranty.

This warranty is only applicable to a product purchased through The Source company-owned stores or participating dealers in Canada where the warranty is included with the product. While this warranty does not confer any legal rights other than those set out above, you may have additional statutory rights which will vary under the laws of the various countries, states, provinces and other governmental entities in which The Source operates. This warranty is subject to all statutory rights you may have in Canada.

