

# LASER EARBUDS

**Operating Instructions** 

#### **FEATURES AND FUNCTIONS**

- 1) Electroluminescence light/microphone control button
- Microphone
- Micro USB port 3)
- Indicator light

### **OPERATION\***

- 1) To turn on the electroluminescence cord, press and hold the button on the main controller until the light activities.
- To play or pause your music, press the button on the main controller once.
- To answer an incoming call, press the button on the main controller once.
- 4) To end the current call, press the button on the main controller once.
- \* Please note: While these operation instructions work with most smartphones, they may not be compatible with all versions due to the setting on the mobile device.

### **CHARGING THIS DEVICE**

- 1) Connect the micro USB port to a compatible power source.
- An LED will light up during charging and turn off when fully charged. Approximate charge time: 2 hours

- Avoid sharply bending or creasing the cable to prevent damaging the light-up feature.
- Do not disassemble or modify the earbuds or cables.
- This product is not waterproof, avoid contact with water.
- Keep away from children as this product may contain small parts that can become a choking hazard.

Note: This item may generate a low intensity noise. This is normal and does not affect performance or sound quality.

## **SPECIFICATIONS**


Driver Size: 10mm 96±3dB Impedance: Frequency Response:

Cable Length:

Plug Type: 3.5mm gold-plated

# Sensitivity:

 $32\Omega \pm 10\%\Omega$ 20Hz-20kHz





The Source warrants that this product will be free from defects in materials and workmanship for a period of six (6) months from the date of purchase. Within this period, simply take the product and your proof of purchase to any The Source store or participating dealer and the product will be replaced (where available) without charge. Any product which has been subject to misuse or accidental damage is excluded from this warranty.

This warranty is only applicable to a product purchased through The Source company-owned stores or participating dealers in Canada where the warranty is included with the product. While this warranty does not confer any legal rights other than those set out above, you may have additional statutory rights which will vary under the laws of the various countries, states, provinces and other governmental entities in which The Source operates. This warranty is subject to all statutory rights you may have in Canada.

Imported by: The Source Barrie, Ontario, Canada, L4M 4W5



For product support please visit www.thesource.ca



© 2016 The Source All rights reserved.