8047793

GADGETREE LIGHT SHOW BLUETOOTH® SPEAKER

Operating Instructions

Thank you for choosing the Gadgetree Light Show Bluetooth[®] Speaker. This portable speaker features 10 light show modes powered by colorful LED lights that flash to the beat of your music and connects wirelessly with any Bluetooth[®] enabled device. It can also be used for hands-free phone calls from your mobile device.

WHAT'S IN THE BOX

- Speaker
- Micro USB charging cable
- 3.5mm audio cable

PRODUCT FEATURES

- 1. ON/OFF
- 2. Last track/Volume-
- 3. Play/Pause/Disconnect
- 4. Next track/Volume+
- 5. LED mode
- 6. Microphone
- 7. USB charging
- 8. LED charging indicator
- 9. 3.5mm jack

OPERATION

- 1. Press the ON/OFF button located on the top of the speaker. When active, the Bluetooth LED under the silicone cover will flash quickly and the speaker's audio will prompt "The Bluetooth[®] is ready to pair".
- Using your Bluetooth[®] enabled smart device, find "Gadget 8047793" from the pairing list. The Bluetooth LED will flash slowly when paired. (Tip: Ensure the Bluetooth[®] is enabled on your device.)
- 3. Upon successful connection, the speaker's audio will emit a tone. The speaker will reconnect automatically if your smart device has been paired previously. When disconnecting, the speaker will pause and prompt "The Bluetooth[®] is ready to pair."
- 4. To power OFF, press and hold the ON/OFF button until you hear 4 short beeps.
- 5. See speaker illustration for general function guidelines.

LIGHT SHOW MODE

- The light show is enabled when music is playing and some modes will react to the beat of your music.
- 1. Press the LED MODE button to advance to the next light show mode.

HANDS-FREE CALLING

- 1. To answer or end an incoming call, press the PLAY/PAUSE button.
- 2. To reject an incoming call, press and hold down the PLAY/PAUSE button for two seconds.

AUDIO INPUT (AUX-IN MODE)


- In addition to Bluetooth®, this speaker can play music using the 3.5mm audio cable included in the box.
- 1. Using the 3.5mm audio cable, connect the speaker to a smart device with 3.5mm audio port. The speaker will emit two beeps when connected.
- 2. When in AUX-IN mode, all speaker functions such as PLAY, PAUSE and TRACK SELECTION will have to be operated from the smart device.
- Tip: If there is no sound during AUX-IN mode, check to ensure the speaker is not already paired via Bluetooth®.

CHARGING THIS DEVICE

- 1. The speaker will emit 4 short beeps when battery is less than 30% capacity.
- 2. Using the micro USB cable included in the box, connect the speaker to a USB charging port.
- 3. The charging indicator will turn red when charging and then turn off when the speaker is fully charged.
- It is recommended to disconnect the charging cable after charging is complete. Do not leave the charging cable inserted when the speaker is not in use.

PRODUCT SPECIFICATIONS

- Bluetooth[®] connection range: 10 meters
- Charging time: Approximately 2.5-3 hours
- Play time: Approximately 5-6 hours
- Battery: built-in 1200mAH Li-On battery
- Output power: 3W
- Frequency response: 90Hz~18KHz
- Impedance: 40HM
 Separative: 00 ID 0 ID
- Sensitive: 80dB±2dB
 S/N Ratio: ≥65dB
- Distortion: ≤1%



SAFETY

- · To clean, wipe gently with a soft, damp cloth
- This speaker is not water-resistant. Keep away from wet or damp surroundings

The FCC Wants You to Know

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- · Increase the separation between the equipment and receiver.
- · Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- · Consult the dealer or an experienced radio/TV technician for additional suggestions.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Where shielded interface cables have been provided with the product or specified additional components or accessories elsewhere defined to be used with the installation of the product, they must be used in order to ensure compliance with FCC regulation.

INDUSTRY CANADA NOTICE RSS247

This device complies with Industry Canada license-exempt RSS standard(s).

Operation is subject to the following two conditions:

(1) this device may not cause interference, and

(2) this device must accept any interference, including interference that may cause undesired operation of the device.

This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus set out in the Radio Interference Regulations of Industry Canada.

IC Number: 255A-8047793

THE SOURCE - WARRANTY



This warranty is only applicable to a product purchased through The Source company-owned stores or participating dealers in Canada where the warranty is included with the product. While this warranty does not confer any legal rights other than those set out above, you may have additional statutory rights which will vary under the laws of the various countries, states, provinces and other governmental entities in which The Source operates. This warranty is subject to all statutory rights you may have in Canada.

Imported by: The Source, Barrie, Ontario, Canada, L4M 4W5



Manufactured in China

For product support please visit www.thesource.ca

