

**OWNER'S MANUAL —**

2308212

Thank you for purchasing the Classic Charger. Please read this manual carefully, it contains important operating instructions.

This charger will quickly and efficiently charge 2 or 4 AA (2000mAh) or AAA (750mAh) Ni-MH batteries. The built-in high-efficiency "switching" power supply will adjust automatically to any voltage from 100-240V AC, for international use.

**Warning:**

- The included batteries are not charged. Please charge prior to first use.
- Charge only Ni-MH type batteries with this charger.
- Batteries may leak or explode causing personal injury if inserted improperly, disposed of in fire, mixed with other battery types, or short circuited.

**Features:**

- Recharge 2 or 4 AA or AAA Ni-MH batteries at a time
- Built-in switching power technology for worldwide (100-240V AC) use
- With USB port for charging handheld devices, including mobile phones, PDAs, iPods, MP3s, MP4s and more
- Safety timer protection
- Automatic charging current selection for AA and AAA batteries
- Equipped with 3 LED lamps to indicate charging mode:  
Red LED light on — Quick charge;  
Red LED off — Charge is completed;  
Green LED light on — USB port is ready for use
- Polarity protection feature

**Charging Instructions:**

1. Insert 2 or 4 pieces of AA/AAA rechargeable Ni-MH batteries into the battery compartment; batteries must be charged in pairs. When charging only two cells, insert the batteries to the left or right side of the charging terminal.
2. Make correct contact for polarity ( + and - ); according to the markings in the battery compartment.
3. Charge AA or AAA or both types together at the same time. To charge both sizes together, place a pair of AA/AAA batteries on the left or right side and the other type of battery in the remaining empty compartment.
4. Plug the charger into any available 100-240V AC outlet. The built-in switching power supply will adjust automatically. When using device overseas, a proper plug adapter may be required (not included). When initially plugging the charger into AC power, the green USB status LED will turn on. Within 10 seconds, the green USB status LED will turn off and the red LED will glow for each location where batteries are installed and receiving a charge.
5. The red LED will turn off to indicate that the charge is completed, and that the batteries are ready for use. The green LED light will turn on to indicate the USB socket is ready for use.
6. Once charging is complete, remove batteries and unplug the charger whenever possible. Do not leave batteries in charger for extended periods of time (more than 1-2 days) OR when the charger is not plugged in. Unplug the charger when not in use.
7. Repeat Step 1 to charge the next set of batteries.

**Using the USB port:**

1. The USB socket will be ready for use only when charging is completed or there is no battery in the charger compartment.
2. The green light (USB) will be turned on to indicate the USB socket is ready for use.
3. Make sure the maximum loading is not exceeding 500mA for the USB socket.

**Specifications:**

<b>Input:</b>	<b>100-240V AC, 50/60 Hz 5W</b>
<b>Output:</b>	<b>AA: 2 x 2.8V DC 350mA 1.96VA AAA: 2 x 2.8V DC 150mA 0.84VA 5VDC 500mA (USB Output)</b>

**Charging Time :**

Type	Capacity	Charging Time	Termination
AA	1800-2000 mAh	5-6 Hours	Manual Manual Timer control
	2100-2300 mAh	6.5-7.5 Hours	
	2400-2800 mAh	8 Hours	
AAA	700-800 mAh	5-6 Hours	Manual Manual Timer control
	900-1000 mAh	6.5-7.5 Hours	
	1100-1200 mAh	8 Hours	

- Charge time will vary depending upon the brand, capacity and condition of batteries being charged.
- After approx. 8 hours charging, the charger will stop automatically, the red LED will turn off indicating the charge is completed and the batteries are ready for use. At that time the green LED light will turn on to indicate the USB socket is ready for use.

**IMPORTANT SAFETY INSTRUCTIONS—SAVE THESE INSTRUCTIONS**

1. **DANGER—TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK FOLLOW THESE INSTRUCTIONS**
2. For connection to a supply outside of North America, use an attachment plug adapter of the proper configuration for the power outlet.
3. Before charging, read instructions carefully.
4. This charger is intended for use with nickel-metal-hydride rechargeable batteries only. Attempting to charge other types of batteries may cause personal injury and damage to the charger.
5. Do not charge non-rechargeable batteries.
6. Do not expose charger to rain or moisture. For indoor use only.
7. Remove from electrical outlet when not in use.
8. Never use an extension cord or any attachment not recommended by manufacturer, this could result in risk of fire, electric shock or personal injury.
9. Do not operate the charger if it has been subjected to shock or damage. Take it to a qualified serviceman for repair.
10. Do not disassemble the charger. Incorrect reassembly may result in a risk of electric shock or fire.
11. Unplug the charger from outlet before attempting any maintenance or cleaning. Use a damp cloth to clean the surface, do not immerse into water.
12. Before disposing of your charger, remove the batteries from the unit.
13. The appliance is not intended for use by young children or infirm persons without supervision. Young children should be supervised to ensure that they do not play with the appliance.
14. This power unit is intended to be correctly orientated in a vertical or floor mount position.

**Can ICES-3(B)**

**THE SOURCE - WARRANTY**



The Source warrants that this product will be free from defects in materials and workmanship for a period of one (1) year from the date of purchase. Within this period, simply take the product and your proof of purchase to any The Source store or participating dealer and the product will be replaced (where available) without charge. Any product which has been subject to misuse or accidental damage is excluded from this warranty.

This warranty is only applicable to a product purchased through The Source company-owned stores or participating dealers in Canada where the warranty is included with the product. While this warranty does not confer any legal rights other than those set out above, you may have additional statutory rights which will vary under the laws of the various countries, states, provinces and other governmental entities in which The Source operates. This warranty is subject to all statutory rights you may have in Canada.

Imported by:

The Source, Barrie, Ontario, Canada, L4M 4W5

Manufactured in China

For product support please visit [www.thesource.ca](http://www.thesource.ca)

© 2015 The Source All rights reserved.



Please Recycle